

## TECHNICAL DATA

<b>ethernet module protocol</b>	K3 USR TCP, IP, UDP, ARP, ICMP, DNS, DHCP
<b>network interface serial port</b>	HTTP, Web socket, HTTPD client, MODBUS 10/100 Mb/s, MDI/MDIX, auto switch
<b>isolation receiver control</b>	RS 485 - half duplex RS 422 - full duplex
<b>transmitter control</b>	2,5 kV (RS485/RS422) by signal TxD permanent
<b>data bit</b>	Tx enable (set by SW)
<b>stop bit</b>	5, 6, 7, 8
<b>parity</b>	1, 2
<b>transfer rate</b>	None, Even, Odd, Space, Mark
<b>transferred signals setting</b>	600b/s – 512kb/s
<b>optical indication</b>	RxD, TxD
<b>connector RS422/RS485</b>	internal web server, PC built-in SW, serial command
<b>connector Ethernet</b>	RxD, TxD, Tx enable, Link activity, half duplex, full duplex, PWR
<b>connector supply</b>	D-SUB 9 pin M
<b>input supply</b>	RJ45
<b>dimension</b>	plug 1.3mm 5 - 32V DC max 2W 95 x 57 x 28 mm



PRO serie

**PRO 4.0/485 κ3**  
*isolated converter*  
**RS422/RS485 - Ethernet**



ver. 1.5, rev 01/2016

## CONDITIONS OF WARRANTY

ComErgon provides full warranty of 24 month  
for serial interface module PRO 4.0/485 starting on the day of purchase.  
The warranty is except for the cases in which the functioning of the module has been affected  
by faulty manipulation, natural catastrophes or other external factors.




Cachticka 23, 831 06 Bratislava  
Slovak Republic


tel.: +421- 950 535 250

e-mail: [service@comergon.sk](mailto:service@comergon.sk)  
http: [www.comergon.sk](http://www.comergon.sk)

## LAYOUT



mode RS422 (J1 1\_2, J4 OFF, J2 OFF)



## SETTING (\* standard setting)

**J1** transmitter control

- 1\_2** permanent ON (mode RS422)
- 2\_3** controlled by TxENable (mode RS485) \*

**J2** receiver control

- OFF** permanent ON
- ON** inverse to TxD \*

**J3** link


- 1\_2** 120R \*
- 3\_4** pull up \*
- 5\_6** pull down \*

**J4** mode selection - RS422/RS485

- OFF** RS422
- 1\_2, 3\_4** RS485 \*

+ set mode (RS485 or RS422) by setting SW of K3 module

mode RS485 (J1 2\_3, J2 ON, J4 1\_2, 3\_4) \*



**RELOAD – default configuration IP: 192.168.0.7**

**name: admin, password: admin**

- Postup:
- 1/ disconnect power supply
  - 2/ set jumper Reload
  - 3/ connect power supply and wait 10s
  - 4/ **!!! disconnect jumper Reload !!!**